

# **C** Battery Cartridge Replacement


Recycle




For information on recycling the used battery, see the Used Battery Information sheet included with the replacement battery.

Back-UPS
BN1250LCD
BR1000-CH, BR1100CI, BR1100CI-RS, BR1100CI-AS, BR1100CI-IN, BR1200LCDI, BR1300LCD, BR1500LCD, BR1500LCDI
BX900R, BX1200R, BX1300LCD, BX1300LCD-CN, BX1500LCD
DL1000VNT


PRESS RELEASE TABS AND SLIDE OFF BATTERY DOOR.




2 DISCONNECT THE BATTERY WIRES.




3 REPLACE THE NEW BATTERY AND CONNECT THE WIRES.




4 CLOSE THE BATTERY DOOR.



# Back-UPS BK 200/500 Back-UPS Pro Smart-UPS SU 280/420





#### Back-UPS Pro USB 350/500/650




#### Back-UPS Office 250/500








### Back-UPS 1000/1400





#### Back-UPS ES350/ES500





disconnect wires, replace with new battery and reconnect wires.










# Back-UPS ES 350/450/550/650/725/750 (120 V) Back-UPS ES 400/550/700 (230 V)

press release tabs and slide off cover




disconnect wires, replace with new battery and reconnect wires.







close cover


# **Smart-UPS Rack-mount (5.25-inch models)**








MODELS 700-1400





MODELS 2200-3000


## **Smart-UPS Rack-mount (8.75-inch models)**




## **Smart-UPS Rack-mount XL Battery Packs**









#### **Smart-UPS 2200/3000**



#### **UXBP 24/48/48M**



#### **SmartCell XR**



## Smart-UPS 450/1500 Smart-UPS XLBP

